
























Hardware Included

		
Cam & Pin x 29	28mm Wood Screws x 12	Handle Screws x 2
		
1 Inch Nail x 27	Door Hinges x 2	Handle x 1
		
14mm Wood Screws x 30	Drying Rack x 1	Gas Strut x 2
		
Door Buffer x 2	Sticker on Cam Caps x 8	Sticker on Caps x 12



Tools you will need

To put your cabinets together you will need the following tools.


 Cordless drill with: • Number 2 Phillips head bit • 4.5mm drill bit • Number 12 countersinking drill bit	 Tape Measure	 Pencil	 Hammer	 Clamps (Quick Release)	 Safety Gear	 Phillips Head Screw Driver
 Spirit Level (900mm recommended)	 Masking Tape	 65mm Wood Screw	 Wall Fixing (If Necessary)			

Important notice


- Make sure you leave plumbing and electrical work to qualified trades people. Never try this yourself.
- If you have any questions contact us on **1800 666 078** Monday to Friday between 8:00am and 6:00pm AEST or email: info@flatpax.com.au.




STEP 1




STEP 2




STEP 3




STEP 4



STEP 5




STEP 6




note: The white side of the back panel should face inside the cabinet.


STEP 7



STEP 8






STEP 9




Pull the black tab to remove the guide from the drawer runner.


note: Make sure the spaces are installed in the correct order as per the above steps.




STEP 10




STEP 11





STEP 12




STEP 13




STEP 14



STEP 15




STEP 16




STEP 17


To remove the gas strut from the bracket use a flat head screw driver to lift the metal strap on either end of the strut.




note: the gas strut can be adjusted by moving the bracket on the door forwards or backwards.




STEP 18



STEP 19




STEP 20



Check cabinets are level then clamp together.
Pre-drill using 2mm drill bit and attach
cabinets together.

STEP 21



Caution: Please ensure all cabinets are screwed into your timber stud wall using a minimum of 65mm timber screws. If attaching to concrete, brick, steel or any other substrates seek advice from your hardware specialist.